

WORK STATION BRACKETS

Installation Instructions



Supports should be spaced no more than 16" to 20" apart for optimum performance

- 1) Select the appropriate size bracket for your counter surface. The overhang should be maximum of 6" longer than the bracket and a minimum of 3" to reduce visibility. The Workstation Brackets are reversible so either leg can be used depending on desired length.
- 2) Locate the wall studs and hold the bracket directly over stud at the desired height. (Brackets must be installed into wall studs. Drywall anchors should not be used)
- 3) Mark on the wall the locations of the holes to be drilled, set the bracket aside.
- 4) Drill 3/16" pilot holes on the marked locations. Place bracket back into position and secure with 1/4" lag bolts. (not supplied) Check for level and shim if necessary.
- 5) Apply a silicone sealant to the top of the brackets to secure the counter surface to the brackets.
Load limit range of 1,420 lbs. to 2,920 lbs. per pair.